











## How Can I Setup the Belimo Energy Valve (EV3, EV4) and the Thermal Energy Meter (TEM)?

<b>Belimo Assistant 2</b> 	<b>Direct NFC</b> 		Device powered	X
			Device unpowered	✓
			Device powered	✓
			Device unpowered	✓
<b>Belimo Assistant</b> 	<b>With ZIP-BT-NFC</b> 		Device powered	✓
			Device unpowered	✓
<b>Local webserver</b> 	<b>Ethernet RJ45</b>  <p>Webbrowser  <a href="http://169.254.1.1">http://169.254.1.1</a>  <a href="http://belimo.local">http://belimo.local</a></p> <p>Webserver</p>	Microsoft Edge Mozilla Firefox Google Chrome Safari on iOS	Device powered	✓
			Device unpowered	X