

Technical data sheet

ZoneTight™, 3-way, Internal thread

For closed cold and warm water systems
For switching functions and 2-point controls on the water side of air-handling units and heating systems

• Snap-assembly of the actuator







Type overview DN

Z3050Q-H 15	туре	DN
	/ 3U5UU-H	15

Technical data

Functional data	Valve size [mm]	0.5" [15]		
	Fluid	chilled or hot water, up to 60% glycol		
	Fluid Temp Range (water)	36212°F [2100°C]		
	Body Pressure Rating	360 psi		
	Close-off pressure ∆ps	40 psi 40psi linear 0%		
	Differential pressure Δpmax			
	Flow characteristic			
	Leakage rate			
	Pipe connection	Internal thread		
		NPT (female)		
	Installation orientation	upright to horizontal (in relation to the stem)		
	Servicing	maintenance-free		
	Flow Pattern	3-way Diverting		
	Cv	2.7		
Materials	Valve body	forged brass		
	Stem	brass		
	Stem seal	EPDM O-ring		
	Seat	PTFE, O-Ring EPDM		
	O-ring	EPDM (lubricated)		
	Ball	chrome plated brass		
Suitable actuators	Non Fail-Safe	CQB(X)		
	Electrical fail-safe	CQKB(X)		

Safety notes



WARNING: This product can expose you to lead which is known to the State of California to cause cancer and reproductive harm. For more information go to www.p65warnings.ca.gov
 If temperature exceeds 212°F operating range due to a boiler control failure the valve will safely contain the hot water but manufacturers product warranty becomes invalid. Valve and actuator replacement is at the expense of others.




Product features

A	pplication	The QCV zone valves are suited for ability to change flow is desired. Co VAV reheat coils, fin tube casing, ra restricted areas and can be assem	ommon applications in adiant panels and duc	nclude unit ventilators, t coils. The valve fits in	, fan coil units,
Flow/Mounti	ng details				
Operat	ting mode	The change-over zone valve is adju by an on/off signal.	usted by a rotary actua	tor. The rotary actuato	or is controlled
Simple direct	mounting	Tool-free snap assembly.			
		The actuator can be plugged on th must match the holes on the flang	-	ion! Just vertical mover	nents). Pins
		The mounting orientation in relation the times)	on to the valve can be	selected in 180° increr	nents. (Possible
stallation notes					

Inst

Permissible installation orientation

The ball valve can be installed upright to horizontal. The ball valve may not be installed in a hanging position, i.e. with the stem pointing downwards.



Water quality requirements Belimo valves are regulating devices. For the valves to function correctly in the long term, they must be kept free from particle debris (e.g. welding beads during installation work). The installation of a suitable strainer is recommended.

> Servicing Ball valves and rotary actuators are maintenance-free.


> > Before any service work on the control element is carried out, it is essential to isolate the rotary actuator from the power supply (by unplugging the electrical cable if necessary). Any pumps in the part of the piping system concerned must also be switched off and the appropriate slide valves closed (allow all components to cool down first if necessary and always reduce the system pressure to ambient pressure level).

> > The system must not be returned to service until the ball valve and the rotary actuator have been correctly reassembled in accordance with the instructions and the pipeline has been refilled by professionally trained personnel.






Direction of flow in both directions possible. Flow direction



Flow setting At the actuator the end stop clip has to be removed in order to get the angle of rotation of 90°, which is needed for the change-over functionality.




Remove end stop clip

Dimensions

Туре	DN	Weight	
Z3050Q-H	15	0.42 lb [0.19 kg]	







On/Off, Electrical fail-safe, 24 V

- Nominal voltage AC/DC 24 V
- Control On/Off





Technical data

Electrical data	Nominal voltage	AC/DC 24 V		
	Nominal voltage frequency	50/60 Hz		
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V		
	Power consumption in operation	2.5 W		
	Power consumption in rest position	0.5 W		
	Transformer sizing	5 VA		
	Auxiliary switch	1x SPST, 1 A resistive @ DC 30 V		
	Switching capacity auxiliary switch	1 A resistive @ DC 30 V		
	Electrical Connection	22 GA plenum cable, 3 ft [1 m], with 1/2" NPT conduit connector		
	Overload Protection	electronic thoughout 090° rotation		
	Electrical Protection	actuators are double insulated		
Functional data	Bridging time (PF)	2 s		
	Pre-charging time	520 s		
	Angle of rotation	90°		
	Angle of rotation note	adjustable with mechanical stop		
	Running Time (Motor)	75 s / 90°		
	Running time fail-safe	<60 s		
	Noise level, motor	35 dB(A)		
	Noise level, fail-safe	35 dB(A)		
	Position indication	pointer		
Safety data	Power source UL	Class 2 Supply		
	Degree of protection IEC/EN	IP40		
	Degree of protection NEMA/UL	NEMA 2		
	Enclosure	UL Enclosure Type 2		
	Agency Listing	cULus acc. to UL60730-1A/-2-14, CAN/CSA E60730-1:02 CE acc. to 2014/30/EU and 2014/35/EU		
	Quality Standard	ISO 9001		
	UL 2043 Compliant	Suitable for use in air plenums per Section 300.22(C) of the NEC and Section 602 of the IMC		
	Ambient humidity	Max. 95% RH, non-condensing		
	Ambient temperature	35104°F [240°C]		
	Storage temperature	-40176°F [-4080°C]		
	Servicing	maintenance-free		



COKB34 C LL

Technical data

BELIMO		Technical data sheet		CQKB24-S-LL
Technical data				
	Weight	Weight	0.57 lb [0.26 kg]	
	Materials	Housing material	UL94-5VA	
Product features				
Ap	plication	Electrical fail-safe On/Off ZoneTight actuator.		
			e in accordance with the flow parameters mounted directly to the valve without the	•
		The actuator operates in respo	onse to AC/DC 24 V.	
		Angle of rotation is adjustable	with the integrated mechanical stop.	
Electrical installation				
		observed. Actuators may also be powered Actuators with plenum cable do One built-in auxiliary switch, 1x interlock control, fan startup, et Meets cULus requirements with Apply only AC line voltage or on Mixed or combined operation or Warning! Live electrical compon During installation, testing, serv to work with live electrical comp who has been properly trained i	by DC 24 V. not have numbers; use color codes inste SPST 1 A @ DC 30 V (resistive load), for en- c. out the need of an electrical ground con- ly UL-Class 2 voltage to the terminals of a f line voltage/safety extra low voltage is n ents! ricing and troubleshooting of this product ionents. Have a qualified licensed electric n handling live electrical components pe fety precautions when exposed to live electrical	ead. nd position indication, nection. auxiliary switches. not allowed. t, it may be necessary cian or other individual rform these tasks.
Wiring diagrams AC 24 V Transformer		Auxilian	y Switch	
Line Volts				

Functions

0% 🗳

100% 💐

Fail Position

Α

ト

/-

100% Open

2

0

S2

NO