

## ZoneTight™, 3-way, Sweat

• For closed chilled and hot water systems

 For switching functions and 2-point controls on the water side of air-handling units and heating systems

• Snap-assembly of the actuator







Picture may differ from product

#### Type overview

Туре	DN
Z3075QS-J	20

### **Technical data**

Functional data	Valve size [mm]	0.75" [20]		
	Fluid	chilled or hot water, up to 60% glycol		
	Fluid Temp Range (water)	36212°F [2100°C]		
	Body Pressure Rating	360 psi		
	Close-off pressure ∆ps	40 psi 40psi		
	Differential pressure Δpmax			
	Flow characteristic	linear		
	Leakage rate	0%		
	Pipe connection	Sweat		
	Installation orientation	upright to horizontal (in relation to the spindle)		
	Servicing	maintenance-free		
	Flow Pattern	3-way Diverting		
	Cv	4.6		
Materials	Valve body	forged brass		
	Stem	brass		
	Stem seal	EPDM O-ring		
	Seat	PTFE, O-Ring EPDM		
	O-ring	EPDM (lubricated)		
	Ball	chrome plated brass		
Suitable actuators	Non Fail-Safe	CQB(X)		
	Electronic fail-safe	CQKB(X)		

## Safety notes



WARNING: This product can expose you to lead which is known to the State of California to cause cancer and reproductive harm. For more information go to www.p65warnings.ca.gov
If temperature exceeds 212°F operating range due to a boiler control failure the valve will safely contain the hot water but manufacturers product warranty becomes invalid. Valve and actuator replacement is at the expense of others.




#### **Product features**

Application	The QCV zone valves are suited for large comme ability to change flow is desired. Common applie VAV reheat coils, fin tube casing, radiant panels restricted areas and can be assembled without t	cations include unit ventilators, fan coil units, and duct coils. The valve fits in space
Flow/Mounting details		
Operating mode	The change-over zone valve is adjusted by a rota by a rota by an on/off signal.	ary actuator. The rotary actuator is controlled
Simple direct mounting	Tool-free snap assembly.	
	The actuator can be plugged on the valve by har must match the holes on the flange.	nd (Caution! Just vertical movements). Pins
	The mounting orientation in relation to the valve two times)	e can be selected in 180° increments. (Possible
tallation notes		

# Insta

Permissible installation orientation

The ball valve can be installed upright to horizontal. The ball valve may not be installed in a hanging position, i.e. with the stem pointing downwards.



Water quality requirements Belimo valves are regulating devices. For the valves to function correctly in the long term, they must be kept free from particle debris (e.g. welding beads during installation work). The installation of a suitable strainer is recommended.

> Servicing Ball valves and rotary actuators are maintenance-free.


> > Before any service work on the control element is carried out, it is essential to isolate the rotary actuator from the power supply (by unplugging the electrical cable if necessary). Any pumps in the part of the piping system concerned must also be switched off and the appropriate slide valves closed (allow all components to cool down first if necessary and always reduce the system pressure to ambient pressure level).

> > The system must not be returned to service until the ball valve and the rotary actuator have been correctly reassembled in accordance with the instructions and the pipeline has been refilled by professionally trained personnel.






Direction of flow in both directions possible. Flow direction



Flow setting At the actuator the end stop clip has to be removed in order to get the angle of rotation of 90°, which is needed for the change-over functionality.




Remove end stop clip

# Dimensions

Туре	DN	Weight	
Z3075QS-J	20	0.53 lb [0.24 kg]	







### On/Off, Electrical fail-safe, 24 V

- Nominal voltage AC/DC 24 V
- Control On/Off





# **Technical data**

Electrical data	Nominal voltage	AC/DC 24 V	
	Nominal voltage frequency	50/60 Hz	
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V	
	Power consumption in operation	2.5 W	
	Power consumption in rest position	0.5 W	
	Transformer sizing	5 VA	
	Auxiliary switch	1x SPST, 1 A resistive @ DC 30 V	
	Switching capacity auxiliary switch	1 A resistive @ DC 30 V	
	Electrical Connection	22 GA plenum cable, 3 ft [1 m], with 1/2" NPT conduit connector	
	Overload Protection	electronic thoughout 090° rotation	
	Electrical Protection	actuators are double insulated	
Functional data	Bridging time (PF)	2 s	
	Pre-charging time	520 s	
	Angle of rotation	90°	
	Angle of rotation note	adjustable with mechanical stop	
	Running Time (Motor)	75 s / 90°	
	Running time fail-safe	<60 s	
	Noise level, motor	35 dB(A)	
	Noise level, fail-safe	35 dB(A)	
	Position indication	pointer	
Safety data	Power source UL	Class 2 Supply	
	Degree of protection IEC/EN	IP40	
	Degree of protection NEMA/UL	NEMA 2	
	Enclosure	UL Enclosure Type 2	
	Agency Listing	cULus acc. to UL60730-1A/-2-14, CAN/CSA E60730-1:02 CE acc. to 2014/30/EU and 2014/35/EU	
	Quality Standard	ISO 9001	
	UL 2043 Compliant	Suitable for use in air plenums per Section 300.22(C) of the NEC and Section 602 of the IMC	
	Ambient humidity	Max. 95% RH, non-condensing	
	Ambient temperature	35104°F [240°C]	
	Storage temperature	-40176°F [-4080°C]	
	Servicing	maintenance-free	



COKB34 C LL

Technical data
----------------

BELIMO		Technical data sheet		CQKB24-S-LL	
Technical data					
	Weight	Weight	0.57 lb [0.26 kg]		
	Materials	Housing material	UL94-5VA		
Product features					
Ap	plication	Electrical fail-safe On/Off Zone	Tight actuator.		
		Valve selection should be done in accordance with the flow parameters and system specifications. The actuator is mounted directly to the valve without the need for tools or additional linkage.		•	
		The actuator operates in respo	onse to AC/DC 24 V.		
		Angle of rotation is adjustable	with the integrated mechanical stop.		
Electrical installation					
		observed. Actuators may also be powered Actuators with plenum cable do One built-in auxiliary switch, 1x interlock control, fan startup, et Meets cULus requirements with Apply only AC line voltage or on Mixed or combined operation or <b>Warning! Live electrical compon</b> During installation, testing, serv to work with live electrical comp who has been properly trained i	by DC 24 V. not have numbers; use color codes inste SPST 1 A @ DC 30 V (resistive load), for en- c. out the need of an electrical ground con- ly UL-Class 2 voltage to the terminals of a f line voltage/safety extra low voltage is n ents! ricing and troubleshooting of this product ionents. Have a qualified licensed electric n handling live electrical components pe fety precautions when exposed to live electrical	ead. nd position indication, nection. auxiliary switches. not allowed. t, it may be necessary cian or other individual rform these tasks.	
Wiring diagrams AC 24 V Transformer		Auxilian	y Switch		
Line Volts					

Functions

0% 🗳

100% 💐

Fail Position

Α

ト

/-

100% Open

2

0

**S**2

NO