

Differential pressure sensor Air dual

Differential pressure transmitter with two independent measuring systems. With 8 selectable ranges each and Modbus functionality. For monitoring over-, under- or the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts as well as the use in pressure differential systems. IP65 / NEMA 4X rated enclosure.







Type Overview					
Туре	Measuring range [Pa]	Communication	Output signal active pressure	Output signal active volumetric flow	Burst pressure
22ADP-154D	-1002500	Modbus RTU	05 V, 010 V	05 V, 010 V	40 kPa
Technical data					
	Electrical data	Nominal voltage		AC/DC 24 V	
		Nominal voltage range		AC 1929 V / DC 1535 V	
		Power consumption AC		4.3 VA	
		Power consumption DC		2.3 W	
		Electrical connection		Pluggable spring loaded terminal block max. 2.5 mm ²	
		Cable entry		Cable gland with strain	relief 2x ø6 mm
	Data bus communication	Communication		Modbus RTU	
		Number of nodes		Modbus see interface o	description
	Functional data	Application		Air	
		Multirange		8 measuring ranges se	lectable
		Voltage output		2 x 05 V, 010 V, min	. resistance 10 kΩ
		Output signal acti	ve note	Output 05/10 V select	table with switch
		Typical response t	ime	Adjustable 0.8 s or 4.0	s
	Measuring data	Measured values		Differential pressure Volumetric flow	
		Measuring fluid		Air and non-aggressive	gases
	Specification Flow	Measuring range	volumetric flow	Adjustable via Modbus Default setting: 0750 Selectable units: m³/h,	'000 m³/h
	Specification Pressure	Sensing element technology		Piezo measuring element	



Technical data

Specification Pressure	Measuring range pressure settings	Setting Range [Pa] Range [inch WC] Facto	torv
op comeaning recount	measuring runge pressure securigs	setti	-
		S0 02500 010 💙	
		S1 02000 08	
		S2 01500 06	
		S3 01000 04	
		\$4 0500 02 \$5 0250 01	
		S5 0250 01 S6 0100 00.4	
		S7 -100100 -0.40.4	
	 Accuracy	Deviation compared to the reference device	
		measuring range ≤500 Pa: ±5 Pa	-
		measuring range >500 Pa: ±10 Pa	
	Long term stability	±2.5% FSO (Full Scale Output) / 4 yr.	_
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)	
	Power source UL	Class 2 Supply	
	Degree of protection IEC/EN	IP65	
	Degree of protection NEMA/UL	NEMA 4X	
	Enclosure	UL Enclosure Type 4X	
	EU Conformity	CE Marking	
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-6	
	Quality Standard	ISO 9001	
	UL Approval	cULus acc. to UL60730-1A/-2-6, CAN/CSA	
		E60730-1	
	Type of action	Type 1	
	Rated impulse voltage supply	0.8 kV	
	Pollution degree	3	
	Ambient humidity	Max. 95% RH, non-condensing	
	Ambient temperature	-1050°C [14122°F]	
	Fluid temperature	-1050°C [15120°F]	
Materials	Housing	Cover: PC, orange	
		Bottom: PC, orange	
		Seal: NBR70, black	
		UV resistant	
	Cable gland	PA6, black	

Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.



Remarks

Manual zero-point calibration

After initial commissioning

Technical data sheet

To carry out the zero-point calibration, the device must be connected to the power supply at least 15 minutes beforehand.

Calibration interval

≤250 Pa 3 months

≤500 Pa 6 months

>500 Pa 12 months

Procedure

• Release both tube connectors from the pressure ports + and -


(Carry out the manual zero-point calibration even if the display shows 0.)

- Press the button "Manual zero-point calibration" until the LED lights permanently
- Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (pay attention to + and -)

Indicators and Operation

Indicators

Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



- 1 Fault / sensor failure
- 2 Service / visual inspection due
- 3 TLF (traffic light function) active (thresholds for display colour changes)
- 4 Radio active (not available)
- 5 Status bar
- 6 Measured value (* appears when TLF function is activated for this value)
- Unit of measure
- 8 Measured value

Parts included

Description	Туре
Mounting plate L housing	A-22D-A10
Duct connector kit, PVC tube 2 m, 2x duct connector (plastic) for 22ADP	A-22AP-A08
Cable Gland with strain relief ø68 mm Dowels Screws	

Accessories

Optional accessories	Description	Туре
	Duct connector, Metal, L 40 mm, Tube connection 5 mm	A-22AP-A02
	Duct connector, Metal, L 100 mm, Tube connection 5 mm	A-22AP-A04
	Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm,	A-22G-A01.1
	Multipack 10 pcs.	
	Connection adapter flex conduit, M20, for cable gland 2x 6 mm,	A-22G-A02.1
	Multipack 10 pcs.	



Accessories

Description	Туре
Airflow volume probe 100 mm for round duct, min. 2 m/s, Problength 100 mm	e EXT-AC-R100
Airflow volume probe 125 mm for round duct, min. 2 m/s, Problength 125 mm	e EXT-AC-R125
Airflow volume probe 160 mm for round duct, min. 2 m/s, Prob length 160 mm	e EXT-AC-R160
Airflow volume probe 200 mm for round duct, min. 2 m/s, Prob length 200 mm	e EXT-AC-R200
Airflow volume probe 250 mm for round duct, min. 2 m/s, Prob length 250 mm	e EXT-AC-R250
Airflow volume probe 315 mm for round duct, min. 2 m/s, Prob length 315 mm	e EXT-AC-R315
Airflow volume probe 400 mm for round duct, min. 2 m/s, Problength 400 mm	e EXT-AC-R400
Airflow volume probe 500 mm for round duct, min. 2 m/s, Problength 500 mm	e EXT-AC-R500
Airflow volume probe 630 mm for round duct, min. 2 m/s, Problength 630 mm	e EXT-AC-R630
Airflow volume probe 200 mm for rectangular duct, min. 2 m/s, length 200 mm	, Probe EXT-AC-L200
Airflow volume probe 250 mm for rectangular duct, min. 2 m/s, length 250 mm	, Probe EXT-AC-L250
Airflow volume probe 300 mm for rectangular duct, min. 2 m/s, length 300 mm	, Probe EXT-AC-L300
Airflow volume probe 400 mm for rectangular duct, min. 2 m/s, length 400 mm	, Probe EXT-AC-L400
Airflow volume probe 500 mm for rectangular duct, min. 2 m/s, length 500 mm	, Probe EXT-AC-L500
Airflow volume probe 600 mm for rectangular duct, min. 2 m/s, length 600 mm	, Probe EXT-AC-L600
Airflow volume probe 700 mm for rectangular duct, min. 2 m/s, length 700 mm	, Probe EXT-AC-L700
Description	Туре
Belimo Duct Sensor Assistant App	Belimo Duct Sensor Assistant
Bluetooth dongle for Belimo Duct Sensor Assistant App	App A-22G-A05
* Bluetooth donale A-22G-A05	

^{*} Bluetooth dongle A-22G-A05

Certified and available in North America, European Union, EFTA States and UK.



Service

Tools connection

This sensor can be operated and parametrised using the Belimo Duct Sensor Assistant App.

When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For the standard operation and parametrisation of the sensor the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select parametrisation in the Belimo Duct Sensor Assistant App



Wiring diagram




Supply from isolating transformer.

The wiring of Modbus RTU (RS-485) is to be carried out in accordance with applicable regulations (www.modbus.org). The device has switchable resistors for bus termination.

Modbus / BACnet: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.



Wiring diagram



yellow: Tx ③ yellow: Rx ④ Status LED ⑤ and ⑥ Factory setting *

Manual zero-point calibration ①

Pressure unit P Response time T Output signal U

red: Error ②

Detailed documentation

The separate document Sensor Modbus-Register informs about Modbus register, addressing, parity and bus termination (DIP1: address, DIP2: baud rate, parity, bus termination)

In addition to the information on the bus, the following analog outputs are available:

-0.4...0.4

AOU1: differential pressure 1

-100...100

S7


AOU2: differential pressure 2

If required, the outputs AOU1 and AOU2 can be changed to volumetric flow via bus system. The volumetric flow is calculated from the differential pressure, the k-factor and the height.

Factory setting for the k-factor is 1.00 and for the height 330 metres above sea level.


The values of the k-factor and the height can be changed via bus system.


Wiring RS-485 Modbus RTU





Dimensions





Туре	Weight
22ADP-154D	0.45 kg

Further documentation

- Modbus Interface description
- Installation instructions