

**Type Overview** 

Differential pressure sensor Air dual with two additional inputs

Differential pressure transmitter with two independent measuring systems. With 8 selectable ranges each and Modbus funtionality. Two additional inputs are available to which a potential-free contact or an NTC10k resistance sensor can be connected. The values at the additional inputs can be read out via Modbus. For monitoring over-, under- or the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts as well as the use in pressure differential systems. IP65 / NEMA 4X rated enclosure.







Туре	Measuring range [Pa]	Commu	nication	Output signal active pressure	Output signal active volumetric flow	Burst pressure	Display type
22ADP-154K	-1002500	Modb	us RTU	05 V, 010 V	05 V, 010 V	40 kPa	LCD
Technical data	l						
	Electrica	al data	Nomina	l voltage	AC/D	C 24 V	
			Nomina	l voltage range	AC 19	29 V / DC 1535 V	
			Power c	onsumption AC	4.3 VA	Ą	
			Power c	onsumption DC	2.3 W	1	
	Data bus communication Functional data		Electrical connection Pluggable spri 2.5 mm <sup>2</sup>		jable spring loaded t m²	erminal block max.	
			Cable e	ntry	Cable	gland with strain re	lief 2x ø6 mm
			Commu	nication	Modb	ous RTU	
			Number of nodes		Modbus see interface description		
			Applicat	tion	Air		
			Multirar	nge	8 mea	asuring ranges selec	table
			Voltage	output		5 V, 010 V, min. re	
			Output	signal active note	Outpo	ut 05/10 V selectab	le with switch
			Display		with k Meas (para Meas	29x35 mm packlight ured values volumet metrisable) ured values pressure metrisable)	
			Typical i	response time	<u>*</u>	table 0.8 s or 4.0 s	
			Notes		Two i poten an NT	ional inputs nputs (IN1 and IN2) ntial-free contact (ma C10k resistance sens or adjustable via Moc	x. 0.3 mA @ 3.3 V) o sor (beta value
	Measuring data		Measur	ed values		ential pressure netric flow	
			Measur	ing fluid	Air an	nd non-aggressive ga	ises



# **Technical data**

Specification Flow	Measuring range volumetric flow	Adjustable via Modbus Default setting: 0750'000 m³/h Selectable units: m³/h, m³/s, cfm	
Specification Pressure	Sensing element technology	Piezo measuring element	
·	Measuring range pressure settings	Setting Range [Pa] Range [inch WC] Fact sett	-
		S0 02500 010	/
		S1 02000 08	
		S2 01500 06	
		S3 01000 04	
		S4 0500 02	
		S5 0250 01 S6 0100 00.4	
		S7 -100100 -0.40.4	
	Accuracy	Deviation compared to the reference device measuring range ≤500 Pa: ±5 Pa measuring range >500 Pa: ±10 Pa	9
	Long term stability	±2.5% FSO (Full Scale Output) / 4 yr.	
	Long term stability	22.5% 150 (tall scale output) 7 4 yt.	
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)	
	Power source UL	Class 2 Supply	
	Degree of protection IEC/EN	IP65	
	Degree of protection NEMA/UL	NEMA 4X	
	Enclosure	UL Enclosure Type 4X	
	EU Conformity	CE Marking	
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-6	
	Quality Standard	ISO 9001	
	UL Approval	cULus acc. to UL60730-1A/-2-6, CAN/CSA E60730-1	
	Type of action	Type 1	
	Rated impulse voltage supply	0.8 kV	
	Pollution degree	3	
	Ambient humidity	Max. 95% RH, non-condensing	
	Ambient temperature	-1050°C [14122°F]	
	Fluid temperature	-1050°C [15120°F]	
Materials	Housing	Cover: PC, orange	
		Bottom: PC, orange	
		Seal: NBR70, black UV resistant	
	Cable gland	PA6, black	
	Capie gialiu	rao, Didek	

22ADP-154



### Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

#### Remarks

### Manual zero-point calibration

After initial commissioning

To carry out the zero-point calibration, the device must be connected to the power supply at least 15 minutes beforehand.

Calibration interval

≤250 Pa 3 months

≤500 Pa 6 months

>500 Pa 12 months

Procedure

• Release both tube connectors from the pressure ports + and -


(Carry out the manual zero-point calibration even if the display shows 0.)

- Press the button "Manual zero-point calibration" until the LED lights permanently
- Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (pay attention to + and -)

## **Indicators and Operation**

#### **Indicators**

Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



- 1 Fault / sensor failure
- 2 Service / visual inspection due
- 3 TLF (traffic light function) active (thresholds for display colour changes)
- 4 Radio active (not available)
- Status bar
- 6 Measured value (\* appears when TLF function is activated for this value)
- Unit of measure
- **8** Measured value

## Parts included

Description	Туре
Mounting plate L housing	A-22D-A10
Duct connector kit, PVC tube 2 m, 2x duct connector (plastic) for	A-22AP-A08
22ADP	



## Parts included

Cable Gland with strain relief ø6...8 mm Dowels Screws

## Accessories

Optional accessories	Description	Туре
	Duct connector, Metal, L 40 mm, Tube connection 5 mm	A-22AP-A02
	Duct connector, Metal, L 100 mm, Tube connection 5 mm	A-22AP-A04
	Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs.	A-22G-A01.1
	Connection adapter flex conduit, M20, for cable gland 2x 6 mm, Multipack 10 pcs.	A-22G-A02.1
	Airflow volume probe 100 mm for round duct, min. 2 m/s, Probe length 100 mm	EXT-AC-R100
	Airflow volume probe 125 mm for round duct, min. 2 m/s, Probe length 125 mm	EXT-AC-R125
	Airflow volume probe 160 mm for round duct, min. 2 m/s, Probe length 160 mm	EXT-AC-R160
	Airflow volume probe 200 mm for round duct, min. 2 m/s, Probe length 200 mm	EXT-AC-R200
	Airflow volume probe 250 mm for round duct, min. 2 m/s, Probe length 250 mm	EXT-AC-R250
	Airflow volume probe 315 mm for round duct, min. 2 m/s, Probe length 315 mm	EXT-AC-R315
	Airflow volume probe 400 mm for round duct, min. 2 m/s, Probe length 400 mm	EXT-AC-R400
	Airflow volume probe 500 mm for round duct, min. 2 m/s, Probe length 500 mm	EXT-AC-R500
	Airflow volume probe 630 mm for round duct, min. 2 m/s, Probe length 630 mm	EXT-AC-R630
	Airflow volume probe 200 mm for rectangular duct, min. 2 m/s, Probe length 200 mm	EXT-AC-L200
	Airflow volume probe 250 mm for rectangular duct, min. 2 m/s, Probe length 250 mm	EXT-AC-L250
	Airflow volume probe 300 mm for rectangular duct, min. 2 m/s, Probe length 300 mm	EXT-AC-L300
	Airflow volume probe 400 mm for rectangular duct, min. 2 m/s, Probe length 400 mm	EXT-AC-L400
	Airflow volume probe 500 mm for rectangular duct, min. 2 m/s, Probe length 500 mm	EXT-AC-L500
	Airflow volume probe 600 mm for rectangular duct, min. 2 m/s, Probe length 600 mm	EXT-AC-L600
	Airflow volume probe 700 mm for rectangular duct, min. 2 m/s, Probe length 700 mm	EXT-AC-L700
Tools	Description	Туре
	Belimo Duct Sensor Assistant App	Belimo Duct Sensor Assistant App
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05
	* Bluetooth dongle A-22G-A05	



#### Service

#### **Tools connection**

This sensor can be operated and parametrised using the Belimo Duct Sensor Assistant App.

When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For the standard operation and parametrisation of the sensor the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

#### Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

### Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select parametrisation in the Belimo Duct Sensor Assistant App



### Wiring diagram




Supply from isolating transformer.

The wiring of Modbus RTU (RS-485) is to be carried out in accordance with applicable regulations (www.modbus.org). The device has switchable resistors for bus termination.

Modbus / BACnet: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.



### Wiring diagram



Manual zero-point calibration ①
red: Error ②
yellow: Tx ③
yellow: Rx ④
Status LED ⑤ and ⑥
Factory setting \*
Pressure unit P
Response time T
Output signal U

		~+) ***	
Setting	Range [Pa]	Range [inch WC]	Factory setting
S0	02500	010	
S1	02000	08	
S2	01500	06	
S3	01000	04	
S4	0500	02	
S5	0250	01	
S6	0100	00.4	
S7	-100100	-0.40.4	

#### **Detailed documentation**

The separate document Sensor Modbus-Register informs about Modbus register, addressing, parity and bus termination (DIP1: address, DIP2: baud rate, parity, bus termination)

In addition to the information on the bus, the following analog outputs are available:

AOU1: differential pressure 1

AOU2: differential pressure 2

If required, the outputs AOU1 and AOU2 can be changed to volumetric flow via bus system.


The volumetric flow is calculated from the differential pressure, the k-factor and the height.

Factory setting for the k-factor is 1.00 and for the height 330 metres above sea level.

The values of the k-factor and the height can be changed via bus system.


The inputs IN1 and IN2 are read out via bus system, further information in the bus system document.


# Wiring RS-485 Modbus RTU





## **Dimensions**





Туре	Weight
22ADP-154K	0.50 kg

# **Further documentation**

- Modbus Interface description
- Installation instructions