

Type Overview

Differential pressure sensor Air

Differential pressure transmitter with 8 selectable ranges and outputs 0...5 V, 0...10 V or 4...20 mA. For monitoring the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts as well as the use in pressure differential systems. Options available with LCD display, auto-zero feature. IP65 / NEMA 4X rated enclosure.





Туре	Measuring range [Pa]	Output signal active pressure	Burst pressure	Display type	Additional features	
22ADP-184	-1002500	05 V, 010 V, 420 mA	40 kPa	-	-	
22ADP-184A	-1002500	05 V, 010 V, 420 mA	40 kPa	-	Auto-Zero	
22ADP-184B	-1002500	05 V, 010 V, 420 mA	40 kPa	LCD	Auto-Zero	
22ADP-184L	-1002500	05 V, 010 V, 420 mA	40 kPa	LCD	-	
Technical data						
	Electrical data	Nominal voltage		AC/DC 24 V		
		Nominal voltage range		AC 1929 V / DC 1535 V		
		Power consumption AC		4.3 VA		
		Power consumption DC		2.3 W		
		Electrical connection		Pluggable spring loaded terminal block max. 2.5 mm ²		
		Cable entry		Cable gland with str	ain relief ø68 mm	
	Functional data	Application		Air		
		Multirange		8 measuring ranges selectable		
		Voltage output		$1~x~05~V,010~V,min.~resistance~10~k\Omega$		
		Current output		1x 420 mA, max. resistance 500 Ω		
		Output signal active note		Output 05/10 V selectable with switch		
		Display		LCD, 29x35 mm		
					with backlight	
				Measured values: Pa (parametrisable)	a, inch WC	
		Typical response time		Adjustable 0.8 s or 4.0 s		
	Measuring data	Measured values			Differential pressure Volumetric flow (with A-22G-A05)	
		Measuring fluid		Air and non-aggress	ive gases	
	Specification Pressure	Sensing element tec	hnology	Piezo measuring ele	ment	



Technical data

Specification Pressure	Measuring range pressure settings	Setting Range [Pa] Range [inch WC] Factory setting			
		S0 02500 010			
		S1 02000 08			
		S2 01500 06			
		S3 01000 04			
		S4 0500 02			
		S5 0250 01			
		S6 0100 00.4			
		S7 -100100 -0.40.4			
	Accuracy	Deviation compared to the reference device			
		measuring range ≤500 Pa: ±5 Pa			
		measuring range >500 Pa: ±10 Pa			
	Long term stability	±2.5% FSO (Full Scale Output) / 4 yr.			
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)			
	Power source UL	Class 2 Supply			
	Degree of protection IEC/EN	IP65			
	Degree of protection NEMA/UL	NEMA 4X			
	Enclosure	UL Enclosure Type 4X			
	EU Conformity	CE Marking			
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-6			
	Quality Standard	ISO 9001			
	UL Approval	cULus acc. to UL60730-1A/-2-6, CAN/CSA E60730-1			
	Type of action	Type 1			
	Rated impulse voltage supply	0.8 kV			
	Pollution degree	3			
	Ambient humidity	Max. 95% RH, non-condensing			
	Ambient temperature	-1050°C [14122°F]			
	Fluid temperature	-1050°C [15120°F]			
Materials	Cable gland	PA6, black			
	Housing	Cover: PC, orange			
		Bottom: PC, orange			
		Seal: NBR70, black			
		UV resistant			

Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.



Remarks

Automated zero-point calibration (Auto Zero)

Transmitters equipped with the auto-zero calibration are maintenance-free.

The auto-zero calibration electronically adjusts the transmitter zero every 10 minutes. The function eliminates all output signal drift due to thermal, electronic or mechanical effects. The auto-zero adjustment takes approx. 4 seconds after which the device returns to its normal measuring mode. During the 4 second adjustment period, the output and display values will freeze to the latest measured value.

Manual zero-point calibration

After initial commissioning

To carry out the zero-point calibration, the device must be connected to the power supply at least 15 minutes beforehand.

Calibration interval

≤250 Pa 3 months

≤500 Pa 6 months

>500 Pa 12 months

Procedure

• Release both tube connectors from the pressure ports + and -


(Carry out the manual zero-point calibration even if the display shows 0.)

- Press the button "Manual zero-point calibration" until the LED lights permanently
- Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (pay attention to + and -)

Indicators and Operation

Indicators

Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



- Fault / sensor failure
- 2 Service / visual inspection due
- 3 TLF (traffic light function) active (thresholds for display colour changes)
- 4 Radio active (not available)
- Status bar
- 6 Measured value (* appears when TLF function is activated for this value)
- 7 Unit of measure
- 8 Measured value

Parts included

Description	Туре
Mounting plate L housing	A-22D-A10
Duct connector kit, PVC tube 2 m, 2x duct connector (plastic) for 22ADP	A-22AP-A08
Dowels	
Screws	



Accessories

Optional accessories	Description	Туре
	Duct connector, Metal, L 40 mm, Tube connection 5 mm	A-22AP-A02
	Duct connector, Metal, L 100 mm, Tube connection 5 mm	A-22AP-A04
	Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs.	A-22G-A01.1
	Airflow volume probe 100 mm for round duct, min. 2 m/s, Probe length 100 mm	EXT-AC-R100
	Airflow volume probe 125 mm for round duct, min. 2 m/s, Probe length 125 mm	EXT-AC-R125
	Airflow volume probe 160 mm for round duct, min. 2 m/s, Probe length 160 mm	EXT-AC-R160
	Airflow volume probe 200 mm for round duct, min. 2 m/s, Probe length 200 mm	EXT-AC-R200
	Airflow volume probe 250 mm for round duct, min. 2 m/s, Probe length 250 mm	EXT-AC-R250
	Airflow volume probe 315 mm for round duct, min. 2 m/s, Probe length 315 mm	EXT-AC-R315
	Airflow volume probe 400 mm for round duct, min. 2 m/s, Probe length 400 mm	EXT-AC-R400
	Airflow volume probe 500 mm for round duct, min. 2 m/s, Probe length 500 mm	EXT-AC-R500
	Airflow volume probe 630 mm for round duct, min. 2 m/s, Probe length 630 mm	EXT-AC-R630
	Airflow volume probe 200 mm for rectangular duct, min. 2 m/s, Probe length 200 mm	EXT-AC-L200
	Airflow volume probe 250 mm for rectangular duct, min. 2 m/s, Probe length 250 mm	EXT-AC-L250
	Airflow volume probe 300 mm for rectangular duct, min. 2 m/s, Probe length 300 mm	EXT-AC-L300
	Airflow volume probe 400 mm for rectangular duct, min. 2 m/s, Probe length 400 mm	EXT-AC-L400
	Airflow volume probe 500 mm for rectangular duct, min. 2 m/s, Probe length 500 mm	EXT-AC-L500
	Airflow volume probe 600 mm for rectangular duct, min. 2 m/s, Probe length 600 mm	EXT-AC-L600
	Airflow volume probe 700 mm for rectangular duct, min. 2 m/s, Probe length 700 mm	EXT-AC-L700
Tools	Description	Туре
	Belimo Duct Sensor Assistant App	Belimo Duct Sensor Assistant App
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05

^{*} EXT-AC-.. Airflow volume probe can only be used in combination with the Bluetooth dongle A-22G-A05 and the Belimo Duct Sensor Assistant App.

Certified and available in North America, European Union, EFTA States and UK.

^{*} Bluetooth dongle A-22G-A05



Service

Tools connection

This sensor can be operated and parametrised using the Belimo Duct Sensor Assistant App.

When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For the standard operation and parametrisation of the sensor the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select parametrisation in the Belimo Duct Sensor Assistant App




Wiring diagram



When switching from 0...10 V to 0...5 V output voltage also the current will be adjusted from 4...20 mA to 4...12 mA.




Wiring diagram



Wiring note power supply AC


For the sensor to function properly, polarity must be observed with a DC supply as well as an AC supply.


If the AC supply is connected incorrectly, i.e. if the wires are reversed, this can lead to the destruction of the sensor.





Dimensions





Further documentation

• Installation instructions