

Guide for System Integrators on how to replace an old EPIV with an EPIV V4

Edition 2024-09/A



### Contents

|                    | Intend of this document          | 4   |
|--------------------|----------------------------------|-----|
|                    | Identify the EPIV version number | 4   |
| BACnet             |                                  |     |
|                    |                                  | 5-6 |
|                    |                                  |     |
| Modbus             |                                  |     |
|                    |                                  | 7-8 |
| Additional dokumer | itation                          |     |
|                    |                                  | 9   |



4

# Introduction

| Intend of this document          | In this document you will find the most important information on replacing<br>an old 2-way EPIV Electric pressure-independent characterized control valve<br>(version 3) with a 2-way EPIV (version 4) from the perspective of BACnet and<br>Modbus. This document focuses only on the interfaces and does not address<br>mechanical or application topics that need to be considered when replacing a<br>device. |   |  |  |  |
|----------------------------------|---|---|--|--|--|
| Identify the EPIV version number | If you want to determine the version number of the EPIV, please check the following.  |   |  |  |  |
|                                  | Version 3   | Version 4   |  |  |  |
| By product type:                 | EPR+MOD, P6WE-MOD   | EPR2+BAC  |  |  |  |
| By Application Software Version: | Version 3.03 / 3.04:  | Version 4.0:  |  |  |  |
|                                  | BACnet:<br>Device object -> Application Software<br>Version 03.0x-xxx   | BACnet:<br>Device object –> Application Software<br>Version EPIV V4.0 |  |  |  |
|                                  | Modbus:<br>Register No. 104 (firmware version)<br>–> 3xx  | Modbus:<br>Register No. 104 (firmware version)<br>–> 101              |  |  |  |
| ZTH EU Tool:                     | supported   | not supported   |  |  |  |
| Belimo Assistant 2:              | not supported   | supported   |  |  |  |

5

## **BACnet**

#### **Overview of changes**

- BACnet Protocol Revision changes from 1.12 to 1.14 in V4.
- In version 4 Binary Value [BV] and Positive Integer Value [PIV] objects were introduced.
- Version 4 supports 5 active COV Subscriptions versus 6 active COV Subscriptions in Version 3.

| Version 3               |   |  | Version 4                   |   |  |  |
|-------------------------|---|--|-----------------------------|---|--|--|
| Object type             | Optional properties                         | Writable<br>properties                               | Object type                 | Optional<br>properties                      | Writable<br>properties                               |  |
| Device                  | Description                                 | Object Identifier                                    | Device                      | Description                                 | Object Identifier                                    |  |
|                         | Location                                    | Object Name  |                             | Location                                    | Object Name  |  |
|                         | Active COV<br>Subscriptions                 | Location   |                             | Active COV<br>Subscriptions                 | Location   |  |
|                         | Max Master                                  | Description  |                             | Max Master                                  | Description  |  |
|                         | Max Info Frames                             | APDU Timeout<br>(1'00060'000)                        |                             | Max Info Frames                             | APDU Timeout<br>(1'00060'000)                        |  |
|                         | Profile Name                                | Number of APDU<br>Retries (010)                      |                             | Profile Name                                | Number of APDU<br>Retries (010)                      |  |
|                         |   | Max Master<br>(1127)                                 |                             |   | Max Master<br>(1127)                                 |  |
|                         |   | Max Info Frames<br>(1255)                            |                             |   | Max Info Frames<br>(1255)                            |  |
| Analog Input [AI]       | Description<br>COV Increment                | COV Increment  | Analog Input [AI]           | Description<br>COV Increment                | COV Increment  |  |
| Analog Output [AO]      | Description<br>COV Increment                | Present Value<br>COV Increment<br>Relinquish Default | Analog Output [AO]          | Description<br>COV Increment                | Present Value<br>COV Increment<br>Relinquish Default |  |
| Analog Value [AV]       | Description<br>COV Increment                | Present Value<br>COV Increment                       | Analog Value [AV]           | Description<br>COV Increment                | Present Value<br>COV Increment                       |  |
| Binary Input [BI]       | Description<br>Active Text<br>Inactive Text | -  | Binary Input [BI]           | Description<br>Active Text<br>Inactive Text | -  |  |
|                         |   |  | Binary Value [BV]           | Description<br>Active Text<br>State Text    | Present Value  |  |
| Multi-state Input [MI]  | Description<br>State Text                   | -  | Multi-state Input [MI]      | Description<br>State Text                   | -  |  |
| Multi-state Output [MO] | Description<br>State Text                   | Present Value<br>Relinquish Default                  | Multi-state Output [MO]     | Description<br>State Text                   | Present Value<br>Relinquish Default                  |  |
| Multi-state Value [MV]  | Description<br>State Text                   | Present Value  | Multi-state Value [MV]      | Description<br>State Text                   | Present Value  |  |
|                         |   |  | Positve Integer Value [PIV] | Description                                 | -  |  |

### Version 3

### **Overview of changes**

If you integrated any of the BACnet object in the list below actions are required, since the object type, the instance no., the unit, or the functionality of the object has been changed. If you do not adapt the implementation of the integration on the controller after the replacement it can lead to errors.

| Version 3       |                           | Version 4        |                           |   |                                       |  |
|-----------------|---------------------------|------------------|---------------------------|---|---------------------------------------|--|
| Object name     | Object type<br>[Inst.No.] | Object name      | Object type<br>[Inst.No.] | Remarks   |                                       |  |
| AbsPos          | AI[2]                     | AbsPos           | AV[2]                     | Object type changed f   | rom Analog Input to Analog Value.     |  |
| RelFlow         | AI[10]                    | RelFlow          | AV[10]                    | Object type changed f   | rom Analog Input to Analog Value.     |  |
| AbsFlow_UnitSel | AI[19]                    | AbsFlow_UnitSel  | AV[19]                    | Object type changed f   | rom Analog Input to Analog Value.     |  |
| Sens1Analog     | AI[20]                    | Sens1Active_Volt | AI[20]                    | Object name changed.  |                                       |  |
| Max             | AV[98]                    | V'max            | AV[94]                    | Object name changed.<br>Instance number chan<br>Not available in positic  | iged.<br>n control.                   |  |
| V'nom_UnitSel   | AV[104]                   | V'nom_UnitSel    | AV[100]                   | Instance number chan  | ged.                                  |  |
| SummaryStatus   | BI[101]                   | SummaryStatus    | MV[99]                    | Object type changed fro   | om Binary Input to Multi-state Value. |  |
| BusTermination  | BI[99]                    | BusTermination   | BV[99]                    | Object type changed from Binary Input to Binary Value.  |                                       |  |
| StatusActuator  | MI[106]                   | StatusActuator   | MV[106]                   | Object type changed from Multi-state Input to Multi-state Value   |                                       |  |
| Override        | MO[1]                     | Override         | MV[1]                     | Object type changed from Multi-state Output to Multi-state Va<br>Override "Mid" not supported anymore. Additional Overrides<br>available. |                                       |  |
|                 |                           |                  |                           | V3  | V4                                    |  |
|                 |                           |                  |                           | 1: None   | 1: None                               |  |
|                 |                           |                  |                           | 2: Open   | 2: Open Valve                         |  |
|                 |                           |                  |                           | 3: Close  | 3: Close Valve                        |  |
|                 |                           |                  |                           | 4: Min_Vmin   | 4: Minimum                            |  |
|                 |                           |                  |                           | 5: Mid_Vmid   | 5: -                                  |  |
|                 |                           |                  |                           | 6: Max_Vmax   | 6: Maximum                            |  |
|                 |                           |                  |                           |   | 7: Nominal                            |  |
|                 |                           |                  |                           |   | 8: -                                  |  |
|                 |                           |                  |                           |   | 9: -                                  |  |
|                 |                           |                  |                           |   | 10: -                                 |  |
|                 |                           |                  |                           |   | 11: Motor Stop                        |  |
| Control Mode    | MV[123]                   | Control Mode     | MV[100]                   | Instance number chan  | ged.                                  |  |
| UnitSelFlow     | MV[121]                   | UnitSelFlow      | MV[123]                   | Instance number chan  | ged.                                  |  |

7

## **Modbus**

#### **Modbus Register Description**

If you integrated any of the registers in the list below actions are required, since the Register No., the unit, the mapping or the functionality of the register has been changed. If you do not adapt the implementation of the integration on the controller after the replacement it can lead to errors.

| Version 3 |  | Versi | Version 4                                    |  |                 |  |  |
|-----------|--|-------|--|--|-----------------|--|--|
| No.       | Register                                     | No.   | Register                                     | Remarks  |                 |  |  |
| 2         | Override control                             | 2     | Override control                             | Override "Mid" not supported anymore.<br>Additional Overrides available.   |                 |  |  |
|           |  |       |  | V3:  | V4:             |  |  |
|           |  |       |  | 0: None  | 0: None         |  |  |
|           |  |       |  | 1: Open  | 1: Open Valve   |  |  |
|           |  |       |  | 2: Close   | 2: Close Valve  |  |  |
|           |  |       |  | 3: Min   | 3: Minimum Flow |  |  |
|           |  |       |  | 4: Mid   | 4: -            |  |  |
|           |  |       |  | 5: MAX   | 5: Maximum Flow |  |  |
|           |  |       |  |  | 6: Nominal      |  |  |
|           |  |       |  |  | 7: -            |  |  |
|           |  |       |  |  | 8: -            |  |  |
|           |  |       |  |  | 9: -            |  |  |
|           |  |       |  |  | 10: Motor Stop  |  |  |
| 3         | Command                                      | 3     | Command                                      | Mapping changed! Adaption, Test and Reset are no<br>longer supported. There is no more need to reset<br>Malfunction & Service Information. |                 |  |  |
|           |  |       |  | V3:  | V4:             |  |  |
|           |  |       |  | 0: None  | 0: None         |  |  |
|           |  |       |  | 1: Adaption  | 1:-             |  |  |
|           |  |       |  | 2: Test  | 2: Sync         |  |  |
|           |  |       |  | 3: Sync  | 3: -            |  |  |
|           |  |       |  | 4: Reset   | 4: -            |  |  |
|           | -  |       | -  | -  |                 |  |  |
| 7         | Relative volumetric flow                     | 7     | Relative Volumetric Flow                     | Range changed from 010'000 to 015'000  |                 |  |  |
| 8         | Absolut volumetric flow                      | 8     | Absolut Volumetric Flow                      | <ul> <li>Unit changed from I/min to I/s</li> <li>Scaling factor changed from 1 to 0.01</li> </ul>  |                 |  |  |
| 9         | Sensor value 1 [mV][-]                       | 13    | Sensor value 1 [mV][-]                       | Register No. changed.  |                 |  |  |
| 11/12     | Absolute volumetric flow<br>in unit selected | 10/11 | Absolute Volumetric Flow<br>in unit selected | Register No. changed.  |                 |  |  |
| 13        | Setpoint analog                              | 12    | Analog Setpoint                              | Register No. changed.  |                 |  |  |

### Version 3

### Version 4

| No. | Register                               | No. | Register                      | Remarks  |   |  |
|-----|--|-----|-------------------------------|--|---|--|
| 105 | Malfunction and Service<br>Information | 105 | Malfunction and Service       | Bit enumeration changed and additional malfunction and service information available                                   |   |  |
|     |  |     |                               | V3   | V4  |  |
|     |  |     |                               | -  | Bit 0: No communication to actuator         |  |
|     |  |     |                               | Bit 1: Mech travel increase  | Bit 1: Gear disengaged                      |  |
|     |  |     |                               | Bit 2: Actuator cannot move  | Bit 2: Actuator cannot move                 |  |
|     |  |     |                               | -  | Bit 3: Reverse flow                         |  |
|     |  |     |                               | -  | Bit 4: Flow setpoint not<br>reached         |  |
|     |  |     |                               | -  | Bit 5: Flow with closed valve               |  |
|     |  |     |                               | -  | Bit 6: Flow actual exceeds flow nominal     |  |
|     |  |     |                               | -  | Bit 7: Flow measurement<br>error            |  |
|     |  |     |                               | Bit 8: Internal activity   | Bit 8: -                                    |  |
|     |  |     |                               | Bit 9: Gear disengaged   | Bit 9: Flowbody tempera-<br>ture error      |  |
|     |  |     |                               | Bit 10: Bus watchdog<br>triggered  | Bit 10: Communication to sensor interrupted |  |
|     |  |     |                               | -  | Bit 11: Freeze warning                      |  |
|     |  |     |                               | -  | Bit 12: Glycol detected                     |  |
|     |  |     |                               | -  | Bit 13: -                                   |  |
|     |  |     |                               | -  | Bit 14: -                                   |  |
|     |  |     |                               | -  | Bit 15: Bus watchdog<br>triggered           |  |
| 107 | Max [%]                                | 107 | V'max [%]                     | Register description and range changed from 3'00010'000 in V3 to 2'50010'000 in V4. Not available in position control. |   |  |
| 108 | Sensor type 1                          | 121 | Sensor 1 Type                 | Register No. changed.  |   |  |
| 111 | Nominal volumetric flow [l/min]        | 111 | Nominal volumetric flow [l/s] | Unit changed from I/min to   | o I/s.                                      |  |

### **Additional documentation**

BACnet

- BACnet Interface description - EPIV (V4)

- BACnet Interface description - EPIV (V3)

Modbus

- Modbus Interface description EPIV (V4)
- Modbus Interface description EPIV (V3)

Further documentation can be found at <u>www.belimo.com</u>.



9

# All inclusive.

Belimo as a global market leader develops innovative solutions for the controlling of heating, ventilation and air-conditioning systems. Damper actuators, control valves, sensors and meters represent our core business.

Always focusing on customer value, we deliver more than only products. We offer you the complete product range for the regulation and control of HVAC systems from a single source. At the same time, we rely on tested Swiss quality with a five-year warranty. Our worldwide representatives in over 80 countries guarantee short delivery times and comprehensive support through the entire product life. Belimo does indeed include everything.

The "small" Belimo devices have a big impact on comfort, energy efficiency, safety, installation and maintenance.

In short: Small devices, big impact.





